

# Aim

The aim of this visualization is to explore the given data using techniques of volumne visualization to find interesting and meaningful visualization.

# Visual Design Type

Volume Visualization showing the object within the raw dataset `data2`.

# Visualization

Volume Visualization showing an animation of the different cross-section of the obejct(fish).



# Visual Mappings

## Legends

Mapping	Range
Bone	
Flesh	
Outer Skin	

## Color Map

A custom color map has been used in this visualizaton. Following are the settings for the preset

No	Value	R	G	B
1	319	1	0.435	0.5568
2	319	1	1	1
3	800.509	0.9098	0.525	0.6078
4	1450.55	1	0.9098	0.945
5	2020.33	1	1	1
6	2871	0.9843	1	0.6705

Opacity Transfer function values

Value	Opacity
319	0.45
1956.13	0.3812
2871	1

## Data Preparation


---

We need to explore the dataset and find the hidden pattern in it. We take the below steps to achieve this.

1. Load the dataset **data2** and specify the Data Extent in properties window with representation as **Surface**. The values used for Data Extent as listed below.

Property	Value:
X	255
Y	255
Z	511
Read As Image Stack	Y

produced the below image



2. Since the previous step didn't show much of object. We will apply the **Contour filter** to find the iso surfaces in the dataset with a **Linear Series** of **10 data points** with range **[0,2871]**, however this would result in a very noisy result which need to be filtered further. A short summary below of the setting is below. **Colormap** used is **X Ray** preset.

Property	Value
Sample size	10
Range	0 - 2871
Type	Linear
Compute Normals	Y
Compute Gradients	N
Compute Scalars	Y
Compute Triangles	Y
Representation	Surface
Data Axes Grid	N

produced the below image



3. Once we have the model for fish ready, we need to get multiple slices inorder to get an cross-section animation.

- Add a **Clip filter** and and position the clipping plane at the start of the fish on z-axis by applying the below settings to get the clips.

Property		Configuration
Clip type		Plane
Show Plane		Y
Invert		Y
Representation		Wireframe
Crinkle clip		Y
Parameters	Origin	(50.70, 53.82, 51.63)
	Normal	(0.0066, -0.00713, -0.999)

- Add animation view from the top menu bar, view -> Animation view. We need to add clips on the animation veiw that would apply **clips at different interval** and keep clipping the fish along **z-axis**.

Property	Configuration
Type	Clip1

Property

Configuration

PropertyClip1 - Clip Type - origin (2)

Animation View

Mode: SequenceTime: 0.630 (?)Start Time: 0End Time: 12No. Frames: 20

Time

00.6315794812

TimeKeeper1 - Time


Clip1 - Clip Type - Origin (2)

Clip1Exact

- Double click on the empty keyframes and add keyframes, that would clip the fish at specified time interval and display the clip selection.

Property	Configuration :
data representation	wireframe
Keyframes	[ 24, 28.101, 32.203, 56.812, 64.265, 71.718, 79.171, 86.825, 90.135, 94.078, 97.804, 101.531, 116.43, 120.164, 123.890, 131.343, 146.25, 161.156, 168.609, 176.0625, 190.96, 205.875, 213.328, 220.781, 228.234, 243.140, 250.593, 265.5, 272.95, 280.40, 310.21, 317.67, 340.031, 362.3990, 377.296, 392.203, 407.109, 429.46, 459.28, 474.18, 496.546, 504 ]
Time	[ 0, 0.093, 0.187, 0.75, 0.93, 1.125, 0.6315, 1.5 , 1.68, 1.78, 1.875, 2.25, 2.343, 2.43, 2.625, 3, 3.375, 3.75, 4.12, 4.5, 4.68, 4.87, 5.062, 5.25, 5.437, 5.625, 6, 6.187, 6.375, 7.125, 7.312, 7.5, 7.875, 8.25, 8.437, 8.62, 8.812, 9 , 9.187, 9.375, 9.56, 9.75, 10.125, 10.5, 11.25, 11.625, 11.812, 12 ]
Mode	Sequence
Start Time	0
End Time	12
No. Frames	20

this will produce a picture like below



## Improvements

---

1. This visualization is limited to the representation of object in the dataset.
2. It could be better visualized with the data about the organs or viens of the fish.